

INSTRUCTIONS FOR UPDATING THE FIRMWARE ON YOUR F-751 AVOCADO QUALITY METER

This applies to Firmware Update Tool V2.0.2.17390 and newer.

1. Download the firmware Update tool to your local computer. This file is posted on the Felix Instruments website and begins with "FirmwareUpdate_". [F-751-Avo Software | Tools for Applied Food Science | felixinstruments.com](#)
2. Download the ANNAvocadoApp.app to your local computer. This file is posted on the Felix Instruments website. [F-751-Avo Software | Tools for Applied Food Science | felixinstruments.com](#)
3. Turn off the F-751, remove the SD card and insert it into the computer.
4. Backup the contents of the SD card.
5. Remove all files from the SD card. This step is optional but promotes a cleaner environment for saving files from the new firmware and app.
6. Copy the ANNAvocadoApp.app to the root directory of the SD card.
7. Run the firmware upgrade tool and follow the on-screen prompts.
8. The firmware upgrade is now complete.